

Pro's Pick

Custom Pickup Beds & Parts

**330 SMITH ST, P.O. BOX 70, ARTHUR ON, N0G 1A0
1-800-865-7366, PH 519-848-5252, FX 519-848-3234**

BED WOOD KITS

A note about bed wood: Pro's Pick bed wood is kiln dried to a very low moisture content. The boards will take on moisture very quickly if they are not protected. As soon as your wood arrives, store in an atmosphere in which the humidity is controlled, (like under your bed in an air conditioned house), or apply two or three coats of the chosen finish, coating all six surfaces of the boards to seal them from moisture. If the finish is marked during assembly, it can be remedied when the final two or three coats are applied.

There are eight boards in our wood kit. Six center boards and two edge boards.

REGULAR BED STRIPS

Place the two edge boards in place. Lay out the other six boards, determine which end of bed strips face the front and lay out, drop the carriage bolts through the strips and proceed. Use large fender washers provided on the bolts located between cross members. Be careful, have a helper watch from above as you tighten the bolts, over tightening will deform the skid strips.

“WOW” STRIPS

If you are using “Wow Strips” the procedure is easier. Lay out the bed wood, slide seven “T” bolt fasteners into each strip, align studs to cross members, position excess T bolts between cross members, apply nuts, lock washers and fender washers between cross members and tighten.

FOR ASSISTANCE PLEASE CALL 1-800-865-7366